



**D**

## 2. Wichtige Hinweise

### Dosierung der Flüssigkeit:

- Standardmäßig wird der Spender mit der maximalen Dosismenge von 1,8 ml pro Hub geliefert.
- Durch Schieben der Gabel nach links wird die Menge auf 1,2 ml pro Hub verringert.
- Durch Schieben der Gabel nach rechts wird die Menge auf 0,8 ml pro Hub verringert.

### Pflege:

- Um eine korrekte Funktion des Spenders zu gewährleisten und auf Grund von Empfehlungen zur Infektionsprävention, sollte der Spender und die Pumpe regelmäßig gereinigt und ggf. desinfiziert werden:
- Zur Reinigung der Pumpe öffnen Sie den Spender. Entnehmen Sie den Behälter mit der Flüssigkeit, um die Pumpe anschließend nach vorn aus dem Spender zu ziehen.
- Die Pumpe sollte nur mit milden Reinigungsmitteln gesäubert werden.
- Bei verklebten Pumpen (z.B. durch Ablagerungen oder lange Standzeiten), muss die Pumpe mit heißem Wasser solange durchgespült werden, bis sie wieder einwandfrei arbeitet.

**Hinweis:** Kunststoffpumpen sind Verschleißteile, die in einem Intervall von 6 Monaten ausgetauscht werden sollten.

**Achtung:** Spender und Pumpe sind nicht autoklavierbar.

**GB**

## 2. Important notice

### Dosing of liquid:

- Delivery is with a max. volume of 1,8 ml per pass. By changing the dosing fork you can reduce the volume.
- By pushing right: approx. 1,2 ml per pass.
- By pushing left: approx. 0,8 ml per pass.

### Maintenance:

- To ensure proper function of the dispenser and to ensure the basis of recommendations for infection prevention and hygiene, the dispenser and the pump should be regularly cleaned and if necessary disinfected:
- For cleaning the pump first remove bottle, then press locking at the wall plate and pull dispenser upwards.
- Hold lever in upper position and pull out the pump backwards. For inserting again go reverse.
- Use gentle cleaning agents only.
- If the pump is blocked (e.g. no use for a longer time), remove bottle and rinse thoroughly with hot water until the work is perfect again.

**Note:** Plastic pumps are spare and wear parts and should be replaced at an interval of six months.

**Attention:** Neither the dispenser nor the pump are autoclavable.